

## ACCLIMATION OF MONTANA GHOST WOOD

To **acclimate**: To adjust to new conditions or an environment.

Proper acclimation of Montana Ghost Wood is essential to favorable product performance. All wood products expand and contract with changes in the ambient moisture; following these tips will help to minimize the movement of the Ghost Wood products after installation:

- 1) Locate the Ghost Wood as close to the point of usage as is practicable. (For indoors, locate in the room of usage.)
- 2) Block off of the ground, cover the top only and protect from direct sunlight and precipitation.
- 3) Stack using spacers between the layers to allow for free air circulation.
- 4) Allow to acclimate for 10-14 days or longer depending on conditions.

The goal is for the moisture content of the Ghost Wood to be as close as possible to that of the place of usage.